



HotTubWorks
Simple Spa Care Guide
with Leisure Time Chemicals & Cleaners

Start-Up

1. Polish the entire spa surface with Fast Gloss prior to filling.
2. Add Metal Gon during the fill cycle (prevents mineral deposits from forming)
3. Use an AquaChek test strip to test your water and balance it accordingly. By adding pH Balance Plus* at this time, you will reduce the need to adjust your pH for up to three months.
4. Add your sanitizer.
5. Test water using a AquaChek Test Strip to make sure water is still balanced.
6. Shock with Renew or OZ.



Weekly

Always allow product to circulate in water for one minute with jets on prior to adding another product. Circulate water for 10 minutes after all products are added.

1. Test water using an AquaChek test strip .Adjust as needed.
2. If needed, add Bright & Clear according to label directions.
3. Add Defender according to label directions.
4. Add Enzyme according to label directions.

After Each Use

IMPORTANT NOTE: It's best to Shock your spa with Renew or Oz IMMEDIATELY AFTER YOU USE IT